

K. Braun, B. Rüppel, L. Weiss, M. Wensing

## Specialized Measurement Techniques Required For Detailed Energy Balancing

In order to improve operation strategies of fuel cells, precise information about

- relative humidity/ water balance,
- crossover and
- nitrogen enrichment are very important.

**!**  
**But:**

- Available **humidity sensors struggle** with the problem of condensation at the sensor head, which leads to a slow response. High relative humidities (RH) are difficult to measure, but are often the case.
- Crossover and nitrogen enrichment cannot be measured directly, **in-situ gas diagnostic is missing.**

## Measuring A Complete Energy Balance Of A Fuel Cell Stack At The Test Stand




Figure 1: Measuring the energy balance of a fuel cell stack at a test bench – relevant measuring parameters (temperature (T), pressure (p), relative humidity (RH), gas composition (GC), mass of liquid water ( $m_w$ ), mass flows ( $\dot{m}$ ), heat loss ( $\dot{Q}$ ))

- All in- and outputs of a component can be described by **thermodynamic state variables and process parameters** e.g. temperature, pressure or heat
- Needed to form mass and energy balances and important for system understanding
- Enable calculation of system efficiencies and development of operation strategies
- **Which data do we need?**  
temperature (T), relative humidity (RH), pressure (p), gas composition (GC), mass of liquid water ( $m_w$ ), mass flows ( $\dot{m}$ ), heat loss ( $\dot{Q}$ )


➔ Gas diagnostics with Raman scattering cover a large amount of required data

## Measurement Technique

**Raman scattering** refers to rare transitions of binding electrons that are excited by light and emit light of a different frequency. The energy change is molecule-specific.

**Raman spectroscopy** measures the intensities of spectral components of scattered light depending on the Raman shift. The spectrum of a gaseous sample gives information about

Gas composition    Temperature    Pressure



### Advantages:

- Contact-free optical measurement of flow → no condensation at the sensor
- In-Situ-measurement
- High sampling rate of 1/s, small focus → interesting for dynamic operation
- Small, portable, robust → flexible usage

## Conclusion & Outlook

- Gas diagnostic with Raman scattering is a powerful measurement tool providing relevant fuel cell data
- Gas composition + thermodynamic parameters => characterization of fuel cells and system components like humidifiers, ejectors etc.



Integration in our self-designed fuel cell test bench => detailed energy balancing

## Data Analysis

### Measurement point:




Figure 2: Example of Raman spectrum of humidified air with detected gas signals

### Temporal resolution:




Figure 3: Derived mole fractions from Raman spectra - measured variations in mass flow (1,2) and in relative humidity (3) @ constant p, T



Calculation of relative humidity (RH) out of mole fraction

## Literature

A. Brauer, In situ spectroscopic techniques at high pressure. Amsterdam, Netherlands: Elsevier, 2015. [Online]. Verfügbar unter: <https://ebookcentral.proquest.com/lib/kxp/detail.action?docID=4188017>

## Acknowledgements

This work was carried out as part of the FCS-HD project, which is funded by the German Federal Ministry of Digital and Transport as part of the National Hydrogen and Fuel Cell Technology Innovation Programme. The funding directive is coordinated by NOW GmbH and implemented by Project Management Jülich (PtJ).

